
TREATMENT AND MAINTENANCE OF STEEL SECTIONAL, ALUMINIUM SECTIONAL AND ROLL-UP GARAGE DOORS.

Maintaining your garage doors is much like washing your car. All exposed surfaces require regular care to guard against corrosion and UV degradation.

REGULAR MAINTENANCE TREATMENT

Inspect all exposed surfaces of the door regularly. In coastal regions, garage doors should be washed thoroughly once a month, while inland, washing them every three months is sufficient. No matter where you live, it is important to follow the steps below.

- STEP 1** Wet the surface of the garage door with a hose.
- STEP 2** Gently wash the door using a microfibre cloth soaked in warm, soapy water that contains a good car soap/wax combination.
- STEP 3** Hose down the door to rinse off any excess soapy water.
- STEP 4** Allow the door to dry.

DO NOT pressure-wash your garage door.

DO NOT use rough or abrasive cloths – these will scratch the door coating.

DO NOT use any window, bleach or solvent cleaning products.

For more information and/or technical advice, contact Swartland's Technical Department on 0861 10 24 25 or customerservice@swartland.co.za

The Hydro Guarantee Certificate is available for download at www.hydrodoors.co.za