

## TREATMENT AND MAINTENANCE OF STEEL SECTIONAL, ALUMINIUM SECTIONAL AND ROLL-UP GARAGE DOORS.

Maintaining your garage doors is much like washing your car. All exposed surfaces require regular care to guard against corrosion and UV degradation.

### REGULAR MAINTENANCE TREATMENT

Inspect all exposed surfaces of the door regularly. In coastal regions, garage doors should be washed thoroughly once a month, while inland, washing them every three months is sufficient. No matter where you live, it is important to follow the steps below.

- STEP 1** Wet the surface of the garage door with a hose.
- STEP 2** Gently wash the door using a microfibre cloth soaked in warm, soapy water that contains a good car soap/wax combination.
- STEP 3** Hose down the door to rinse off any excess soapy water.
- STEP 4** Allow the door to dry.

**DO NOT** pressure-wash your garage door.

**DO NOT** use rough or abrasive cloths – these will scratch the door coating.

**DO NOT** use any window, bleach or solvent cleaning products.



Scan for garage door  
installation instructions

For more information and/or technical advice, contact Swartland's Technical Department on 0861 10 24 25 or [customerservice@swartland.co.za](mailto:customerservice@swartland.co.za)

The Hydro Guarantee Certificate is available for download at [www.hydrodoors.co.za](http://www.hydrodoors.co.za)

---